

Assembly

ADR box



- Start with the closed pallet
 - Follow steps 1-3 to build first layer
 - Note that the plastic panels are always on the inside and the IPP logo on the outside top right
 - IPP tool makes assembly and disassembly easier and quicker (steps 4 and 10)
 - Don't use hammers, screwdrivers or other tools to close the clamps
 - Build walls of second layer (steps 5 - 7)
 - Secure clamps at back with IPP tool
 - Yellow Support bar to stabilise top 3 sidewalls whilst loading with WEEE (step 8)
 - Remove support bar when fully loaded with WEEE
 - Install final wall and secure clamps using IPP tool (step 9)
 - Ensure all clamps are firmly in place
 - Note: IPP tool is reversed for disassembly (10)
- New box cannot be mixed with old